

Installation guide for an unglued gaiter

This is what you receive:



Clean the neoprene with cellulose thinner.



Smear glue on the two ends. And then wait 10-20 minutes.



Assemble the gaiter around the rudderstock.



Open the clamps and put them around the stock. First tighten the lower one around the tube. Then press the top of the gaiter 30-50mm down, so it folds. Tighten the top clamp around the stock.



Turn the rudder to one side, and see the gaiter works well, Do the same to the other side.

